



MOUNTING INSTRUCTIONS
For 45-1299 -GL1800 Chrome Headlight Cover Trims
2012 Model Only

NOTE: Read instructions thoroughly before installing. Work one side at a time.

1. Place bike on center stand.
2. Thoroughly clean outside surface where the cover trim is to be mounted with rubbing alcohol pads provided.
3. Check fitment of the piece.
4. Remove tape backing on chrome accent.
5. Press the accent into place. Hold firmly for 1 minute.
7. Repeat on the other side.
8. Wait at least 6 hours riding.



133 Gold Street, Worcester, MA 06108 Ph: 508-791-7552 800-821-9861 fax 508-793-2919
info@addonaccessories.net www.addonaccessories.net