BIG BIKE PARTS®

Copyright© 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

6/3/2020

INSTALLATION INSTRUCTIONS

PART NO. 52-836/52-836BK | ARMREST BEVERAGE HOLDER

PASSENGER ARMREST

TOOLS NEEDED:	2MM ALLEN WRENCH	PHILLIPS SCREWDRIVER			

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

NOTE: THE ARMREST MOUNT CAN MOUNT ON THE OUTSIDE OR THE INSIDE OF THE ARMREST AND ON THE RIGHT OR THE LEFT SIDE.

Scan code with your smartphone to view video

INSTALLATION:

1. USING A PHILLIPS SCREWDRIVER REMOVE THE TWO SCREWS HOLDING THE ARMREST PAD TO THE ARMREST SUPPORT.
2. TAKE THE NEW MOUNT AND PLACE IT ON THE BOTTOM OF THE ARMREST SUPPORT.
3. REINSTALL THE WASHERS AND SCREW THROUGH ALL OF THE ITEMS AS SHOWN IN FIG. 1.
4. ALIGN ALL OF THE ITEMS AS YOU WANT THEM AND TIGHTEN BOTH SCREWS.
5. SLIDE BEVERAGE HOLDER INTO MOUNT AS SHOWN IN FIG. 2.
6. USING A 2MM ALLEN WRENCH INSTALL THE M3-0.5 X 6MM LONG SCREW THAT CAME WITH THE MOUNT. SEE FIG. 3.




FIG. 1



FIG. 2



FIG. 3

BIG BIKE PARTS®

Copyright© 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

6/3/2020

INSTALLATION INSTRUCTIONS

PART NO. 52-836/52-836BK | ARMREST BEVERAGE HOLDER

PASSENGER ARMREST

TOOLS NEEDED:	2MM ALLEN WRENCH	PHILLIPS SCREWDRIVER			

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

NOTE: THE ARMREST MOUNT CAN MOUNT ON THE OUTSIDE OR THE INSIDE OF THE ARMREST AND ON THE RIGHT OR THE LEFT SIDE.

Scan code with your smartphone to view video

INSTALLATION:

1. USING A PHILLIPS SCREWDRIVER REMOVE THE TWO SCREWS HOLDING THE ARMREST PAD TO THE ARMREST SUPPORT.
2. TAKE THE NEW MOUNT AND PLACE IT ON THE BOTTOM OF THE ARMREST SUPPORT.
3. REINSTALL THE WASHERS AND SCREW THROUGH ALL OF THE ITEMS AS SHOWN IN FIG. 1.
4. ALIGN ALL OF THE ITEMS AS YOU WANT THEM AND TIGHTEN BOTH SCREWS.
5. SLIDE BEVERAGE HOLDER INTO MOUNT AS SHOWN IN FIG. 2.
6. USING A 2MM ALLEN WRENCH INSTALL THE M3-0.5 X 6MM LONG SCREW THAT CAME WITH THE MOUNT. SEE FIG. 3.




FIG. 1



FIG. 2



FIG. 3