

Copyright<sup>®</sup> 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-934L

WIND DEFLECTOR-LOWER

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

12/11/2018

TOOLS NEEDED: 5MM ALLEN WRENCH

DRILL

13/64" (5MM) DRILL BIT

3MM ALLEN WRENCH

8MM WRENCH

**PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.****ESTIMATED INSTALLATION TIME: 60 TO 90 MIN.****INSTALLATION:**

1. STARTING ON THE LEFT SIDE USING A 5MM ALLEN WRENCH REMOVE THE TWO SCREWS SHOWN IN **FIG. 1**.
2. RELEASE THE OUTSIDE TABS ON THE LEFT AIR DEFLECTOR PANEL B FROM THE DEFLECTOR PANEL A. ONCE THE OUTSIDE OF THE DEFLECTOR PANEL IS LOOSE, PULL THE PANEL STRAIGHT OUT TO REMOVE IT. (**FIG. 1**).
3. USE **FIG. 2** TO MARK AND DRILL TWO 13/64" HOLES FROM THE INSIDE OF THE DEFLECTOR PANEL B.
4. ASSEMBLE THE LEFT LOWER WIND DEFLECTOR TO THE MOUNT ASSEMBLY USING THE M5 X 12MM SCREWS ACCORDING TO **FIG. 3**. NOTE: THE CURVE IN THE DEFLECTOR PANEL WILL CURVE TOWARD THE FRONT OF THE BIKE WHEN INSTALLED.
5. INSTALL THE COMPLETED LOWER WIND DEFLECTOR ASSEMBLY ON THE DEFLECTOR PANEL B THROUGH THE TWO HOLES THAT YOU DRILLED USING THE M5 X 10MM SCREWS AS SHOWN IN **FIG. 3**.
6. REINSTALL THE DEFLECTOR PANEL B ON THE BIKE IN REVERSE ORDER WITH THE WIND DEFLECTOR INSTALLED IN PLACE. SEE **FIG. 4**.
7. REINSTALL THE TWO ALLEN SCREWS YOU REMOVED IN STEP 1 TO SECURE THE DEFLECTOR PANEL B.
8. USING A PHILLIPS SCREWDRIVER AND A 8MM WRENCH TIGHTEN THE PIVOT SCREW TO THE DESIRED TENSION.
9. REPEAT ON RIGHT SIDE.

